
1 INTRODUCTION

This manual is designed to help you quickly and easily learn to use your Quantum Composers Model 9314E pulse generator. Rather than the usual array of knobs and switches, the 9314E uses a menu-driven user interface with "on-line" help -- once you learn the basics of operating your 9314E, you may never need to refer to this manual again.

The 9314E has some unique features that are designed exclusively for use as a laser trigger signal generator, but can also be used as a general purpose pulse generator. Because it employs a flexible microprocessor-controlled architecture, the 9314E can be customized to fit your exact requirements -- contact Quantum Composers for details.

Technical Support

For questions or comments about operating the 9314E, contact Quantum Composers via one of the following methods:

P Phone - (406) 582-0227

P Fax - (406) 582-0237

P Email /Internet - www.quantumcomposers.com

Parts List

The following parts are included with the 9314E -- contact Quantum Composers if any parts are missing:

P 9314E Pulse Generator

P AC Power Cord

P User's Manual

P Quick Reference Card

Warranty

In addition to a 30-day money back guarantee, the 9314E has a one-year limited warranty from the date of delivery. This warranty covers defects in material and workmanship. Quantum Composers will repair or replace any defective unit. Contact us for information on obtaining warranty service.

Custom Modifications

The 9314E is microprocessor-controlled and, employs a flexible and expandable user-interface. New features and operating modes often can be added, without hardware modifications, by merely modifying the software contained inside the 9314E. Most modifications can be made for a very modest charge -- contact Quantum Composers for details.

Safety Issues

Normal use of test equipment exposes you to a certain amount of danger from electrical shock because testing must be performed where exposed voltage is present. An electrical shock causing 10 milliamps of current to pass through the heart will stop most human heartbeats. Voltage as low as 35 VDC or RMS AC should be considered dangerous and hazardous since it can produce a lethal current under certain conditions. Higher voltages pose an even greater threat because such voltage can more easily produce a lethal current. Your normal work habits should include all accepted practices that will prevent contact with exposed high voltage, and that will steer current away from your heart in case of accidental contact with a high voltage. You will significantly reduce the risk factor if you know and observe the following safety precautions:

1. Do not expose high voltage needlessly. Remove housings and covers only when necessary. Turn off equipment while making test connections in high-voltage circuits. Discharge high-voltage capacitors after removing power.
2. If possible, familiarize yourself with the equipment being tested and the location of its high voltage points. However, remember that high voltage may appear at unexpected points in defective equipment.
3. Use an insulated floor material or a large, insulated floor mat to stand on, and an insulated work surface on which to place equipment. Make certain such surfaces are not damp or wet.
4. Use the time-proven "one hand in the pocket" technique while handling an instrument probe. Be particularly careful to avoid contacting a nearby metal object that could provide a good ground return path.
5. When testing AC powered equipment, remember that AC line voltage is usually present on some power input circuits, such as the on-off switch, fuses, power transformer etc., any time the equipment is connected to an AC outlet, even if the equipment is turned off.
6. Never work alone. Someone should always be nearby to render aid if necessary. Training in CPR first aid is highly recommended.

1 CONTROLS AND CONNECTORS

This chapter explains the function of each control and connector on the 9314E.

Front Panel

The front panel contains the most frequently used controls and connectors.

Display

The 9314E features a backlit liquid crystal display, on which menu selections and settings are shown. The left half of the display shows the current menu selection, while the right half shows the current setting of the item associated with that menu.

Control Buttons



Item Button

Toggles between the various items in a menu.



Menu Button

Toggles between the various sets of menus.



Up Button

Increments a number or increments the selection for the current item.



Down Button

Decrements a number or increments the selection for the current item.



Left Button

For numeric items, this button is used to select which digit in a numeric entry is selected for editing. For other items or when the left most digit is already selected for numeric items, pressing and holding this button down displays a brief description of the current item.



Right Button

For numeric items, this button is used to select which digit in a numeric entry is selected for editing. For other items or when the right most digit is already selected for numeric items, pressing and holding this button down displays the range and units for the current item.



Stop Button

Disables output of pulses on all channels.



Run Button

Enables output of pulses.

QC Connectors

There are five (5) connectors on the front of the 9314E, 4 outputs and 1 input.

T1

Channel 1 output -- a general-purpose pulse output, with programmable delay for both edges and pulse polarity. The maximum output voltage is adjustable and varies from 20 Volts open-circuit to 10 Volts when driving a 50 Ohm load. The maximum voltage is adjusted by a potentiometer located on the back of the 9314E.

T2

Channel 2 output -- same specifications as Channel 1.

T3

Channel 3 output -- same specifications as Channel 1.

T4 Output

Channel 4 output -- same specifications as Channel 1.

Ext/Gate

External Trigger or Gate signal input -- used as either an external signal to trigger the generation of pulses or as a gate signal to enable and disable the outputs.

Back Panel

Output Voltage Adjustment

The maximum output voltage of all output channels is adjusted by turning the potentiometer labeled **VOUT**. Turn clockwise to increase the voltage, counter-clockwise to decrease the voltage. The maximum voltage possible is 20 Volts into a high-impedance load or 10 Volts into a 50 Ohm load.

Serial Port

This is a 9-pin D-sub connector for the RS232 interface that comes standard with the 9314E. It is pinned to be directly connected to a standard IBM-PC serial port -- use a straight-through cable (not a null modem cable) to connect to a PC.

GPIB Port

A GPIB (IEEE 488) interface is available as an option with the 9314E.

AC Input

A standard IEC instrument-type cord should be used. The 9314E is supplied with a power cord that fits the type of socket used in your country.

Before plugging in, please make sure that the voltage selection switch is set to the proper setting for your country (either 110V or 220V).

Line Voltage Selection

This switch is used to select the voltage level used in your country -- make sure it is on the proper setting or the 9314E could be damaged.



1 OPERATING INSTRUCTIONS

This chapter presents detailed instructions on the operation of the 9314E.

Overview

The 9314E uses a single-line LCD to display menu selections. The front panel keys are used to "navigate" through sets of menus to set various options and control the pulse generator. Some keys are only active at certain times or have different behavior depending on what state the menus are in -- once understood, the menus can be quickly and easily manipulated. The 9314E also contains non-volatile memory for storing up to twelve (12) configurations, so you need not go through the entire setup process each time the instrument is used.

Selecting Menu Items

The menu items in the 9314E are arranged in a set. Pressing the  key will toggle between sets of menus, while the  key will toggle between menu items within the current set. Hold down the Left arrow key to receive a short description of the current menu item. Pressing and holding the Right arrow key will display the valid range for that item.

Numeric Input Mode

When the current item is numeric, the system enters the Numeric Input mode. In this mode, the Left and Right arrow keys are used to select a digit to edit. The selected digit blinks to identify itself as the active digit. The Up and Down arrow keys are then used to increment or decrement this digit. When the left most digit is active, pressing and holding the Left arrow key will display a brief description of the current item. When the right most digit is active, pressing and holding the Right arrow key will display the range and units for the current item.

Item Edit Mode

When the current item is non-numeric, the Up and Down arrow keys are used to select among different options for the entry. The Left and Right arrow keys are used to display a description of the item.

Main Menu

The Main Menu consists of a set of menus selections used to set the operating mode, time period and frequency of the 9314E.

MODE - Pulse Modes

There are five (5) different Pulse modes available.

Continuous Mode

While in Continuous mode, the 9314E will generate pulses at the rate set by the internal To Period as set in the **ToPer** menu.

The Ext/Gate input may be used as a gate or interlock by setting the **GATE** menu to **Low** or **High**. Pulses will then only be generated while the Ext/Gate input is active. Selecting **Low** will make the gate active low, while selecting **High** will make the gate active high. Set to **Off** to disable the gate function.

Note: No pulses are generated until the Run key has been pressed.

External Trigger Mode

In the External Trigger mode, one pulse is output each time an active edge occurs on the Ext/Gate input. The external trigger polarity menu (**TRIG**) is used to determine whether the 9314E is triggered on the rising or falling edge of the external trigger.

Since it is being used as a trigger source, the Ext/Gate input cannot be used as a gate in this mode.

Single Shot Mode

During Single Shot operation, one pulse is generated each time the Run key is pressed. The rate at which pulses are produced is totally dependent on how fast the Run key is pressed.

The external trigger input may be used as a gate or interlock by setting the **GATE** menu to **Low** or **High**. Pulses will then only be generated while the external trigger input is active. Selecting **Low** will make the gate active low, while selecting **High** will make the gate active high.

Duty Cycle

The Duty Cycle mode is similar to Continuous mode in that a continuous stream of pulses is output. The exception is the outputs are only active for a set number of seconds (**DC:On** menu), then disabled for another set time period (**DC:Off** menu) before being re-enabled. The number of cycles is set in the **CYCLES** menu, after which all output cease. Setting the number of cycles to zero results in continuous cycling, until the Stop Key is pressed.

The Ext/Gate input may be used as a gate or interlock by setting the **GATE** menu to **Low** or **High**. Pulses will only be generated while the external trigger input is active. Selecting **Low** will make the gate active low, while selecting **High** will make the gate active high.

The Run key must be pressed to start the Duty Cycle mode.

Burst

Burst mode is similar to Continuous, except only a certain number of pulses will be output (**#BURST** menu), after which outputs are disabled.

The Ext/Gate input may be used as a gate or interlock by setting the **GATE** menu to **Low** or **High**. Pulses will then only be generated while the external trigger input is active. Selecting **Low** will make the gate active low, while selecting **High** will make the gate active high.

The Run key must be pressed to start Burst mode.

GATE - Gate Select

When not in External Trigger mode, the Ext/Gate input on the 9314E can be used as a gate signal. When the gate is enabled, pulses will only be output while the signal into the Ext/Gate input is active -- thus, this signal can act as a safety interlock or external control signal.

The Ext/Gate input may be used as a gate or interlock by setting the **GATE** menu to **Low** or **High**. Pulses will then only be generated while the external trigger input is active. Selecting **Low** will make the gate active low, while selecting **High** will make the gate active high. Setting the **GATE** menu to **Off** will disable the Gate function.

The setting of the **GATE** menu is used to determine when the signal is active. If the gate menu is set (active) **High**, pulses will only be generated if the Ext/Gate input signal is greater than 3.5 Volts. If set to (active) **Low**, outputs will be enabled as long as the Ext/Gate input signal is less than 2.0 Volts.

ToPer - To Period

Except when in External Trigger or Single Shot mode, all pulse outputs are based on an internal timer called To. This menu is used to select the rate at which To runs by selecting the time period in microseconds between timer pulses. When in Continuous, Burst or Duty Cycle mode, pulses are output at the rate determined by To. The frequency of pulse outputs in these modes can be found by taking the reciprocal of the To Period setting.

Channel Menus

This set of menus is used to set the delays for each edge and the polarity of the output channels.

$n = n' +$ - n Delay & Sync Source

Each of the four channels has an independent delay setting for each edge which is set from the delay menu. The format is $n = n' + 00.0000000$ where n (1a, 1b, 2a, 2b, etc.) refers to the current edge and n' (To, 1a, 1b, 2a, 2b, etc.) refers to the sync source for n . n' is automatically restricted from any choice that would generate a degenerate triggering situation in which an edge triggers itself. The delay may be negative or positive relative to n' , but cannot occur before To, the internal sync.

Tn:Pol - Tn Polarity

Each of the four channels has an independent output polarity setting which is set from the Tn:Pol menu, where $n = 1, 2, 3$, or 4.

When set to **Positive**, the "a" edge will be the rising edge and the "b" edge will be the falling edge. If set to **Negative**, the "b" edge will be the rising edge and the "a" edge will be the falling edge.


Store/Recall/Misc. Menus

The 9314E contains non-volatile memory for storing twelve (12) different configurations. The settings of all menu selections are stored and can be quickly recalled.


STORE Configuration

Stores the current menu settings in the specified memory location one (1) - twelve (12).

Note: If you overwrite a particular location, its previous contents are destroyed.


A configuration is stored by using the Up and Down arrow keys to select the memory location number. Press the Left or Right arrow key, at which time you will be prompted to press the  key to verify that you want to overwrite the existing stored configuration. If you press any other key, the configuration will not be saved.

RECALL Configuration

Recalls a previously stored configuration from the specified memory location. To recall a configuration use the Up and Down arrow keys to select the memory location number and press the Left or Right arrow key. You will be prompted to press the  key to verify that you want to overwrite the active configuration. If you press any other key, the configuration will not be recalled.

Note: A zero configuration is available for recall. This configuration resets the instrument to the factory default settings.

Shot Counter

The 9314E includes a nine (9) digit shot counter. A separate count is kept for each configuration. The maximum count displayed is 4,294,967,295, after which the count rolls over to zero. To manually reset the counter to zero, press the Left or Right arrow key, at which time you will be prompted to press the  key to verify that you want to zero the counter. If you press any other key, the shot counter will not be reset.

Fmark


The character used as a decimal point can be set to either a "." (period) or a "," (comma). The period is generally used in North America, while the comma is used in Europe.

Volume

The key click volume may be adjusted from 0 (disabled) to 9. The default value is 2.

GPIB:Addr

This menu sets the GPIB address for systems with the optional GPIB interface. The valid address range is from 0 to 30.



1

1 COMPUTER INTERFACE

The 9314E comes standard with an RS232 serial interface; a GPIB (IEEE-488) interface is available as an option. All menu settings can be set and retrieved over the computer interface using a simple command language.

Serial (RS232) Pinout

The serial port is located on the back of the 9314E, and uses a 9-pin D-type connector with the following pinout (as viewed from the back of the 9314E):

1. No connection
2. Tx - Transmit (to computer)
3. Rx - Receive (from computer)
4. DTR - connected to pin 6
5. Ground
6. DSR - connected to pin 4
7. RTS - connected to pin 8
8. CTS - connected to pin 7
9. No connection

The voltage level of the Transmit signal is +/-10V, the Receive signal should be at least +/-5V.

GPIB

An optional GPIB (also known as IEEE-488) computer interface is available for the 9314E. Before using this interface, the address must be set using the GPIB Address menu item. The same command set is used for both the GPIB and the RS-232 interfaces. Both interfaces may be used at the same time. Responses will be made to the most recently used interface.

Command Language

All menu items can be accessed and selected via the computer interface using a simple command language. The command set is the same for both the RS232 and GPIB interfaces.

Command Protocol

All commands have the following syntax:

\$<name> <##>CR

where

P \$ indicates a command follows.

P <name> is the command name. No spaces are allowed between the \$ and the <name>. The name is case sensitive.

P <##> is an unsigned, integer associated with the command. A space must be inserted between <name> and <##>.

P CR is a carriage return character (ASCII value 13).

With echo enabled, all characters sent will be echoed back to the sender.

Unidentified commands and most out of range conditions result in the pulse generator ignoring the command. If the command is properly identified, the pulse generator returns an **ok** followed by a carriage return and a line feed (ASCII 13, ASCII 10); otherwise it returns a **?1** (a question mark, followed by the number "one", a carriage return and a line feed). A **?2** is sent if a valid command is received but the parameter is out of range.

Example - send the following command to set the number of cycles:

\$CYCLES 100

The pulse generator will return the following:

Echo Enabled: **CYCLES 100<cr><lf>**

ok<cr><lf>

Echo Disabled: **ok<cr><lf>**

Only one command will be processed per message. Commands are not processed until the carriage return is sent. If an error is made and identified prior to sending the carriage return, sending a new \$ will reset the input buffer and allow a corrected command to be sent.

To determine the current value of a parameter the syntax is:

\$<name> ?CR

where name = a valid command name.

This will return an integer followed by a space, carriage return and a line feed character (ASCII 10).

Example - the following command would retrieve the current Cycles setting:

\$CYCLES ?

The pulse generator will return the following:

Echo Enabled: **CYCLES ?<cr><lf>**

100<cr><lf>

Echo Disabled: **100<cr><lf>**

Communication Protocol

Communication parameters are set at 9600 baud, 8 bits, parity = none, and 1 stop bit. To help establish RS232 communications, the pulse generator emits the characters **QC** approximately every 200 ms after power up and until the 9314E receives a **\$**. Both the GPIB and the RS232 interface may be used at the same time. The instrument will respond to the port which sent the command.

Command List

The following table summarizes all the commands.

Note: The name of the commands are identical to how they appear on the display of the 9314E, with channel parameters preceded by a T.

9314E Communication Commands		
Command Name	Parameters	Description
MODE	0 = Continuous mode 1 = Burst mode 2 = Duty Cycle mode 3 = Single Shot mode 4 = External Trigger mode	Sets the pulse generator mode.
GATE	0 = off 1 = active low 2 = active high	Enables the external trigger input to function as a gate controlling all outputs. Cannot be used with external trigger mode.
ToPer	1000 - 999999998	Sets the To internal sync period, in microseconds * 10.
DC:On	1 - 10000 Sec	Sets the on time, in seconds, for the Duty Cycle mode.
DC:Off	1 - 10000 Sec	Sets the off time, in seconds, for the Duty Cycle mode.
TRIG	0 = falling edge 1 = rising edge	Sets the active edge of the Ext/Gate signal when used as an external trigger.
CYCLES	0 - 10000 cycles	Sets the number of cycles for the Duty Cycle mode.
#/BURST	1 - 30000 pulses	Sets the number pulses in the Burst mode.
T1a	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 1a.
T1a=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 1a.
T1b	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 1b.
T1b=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 1b.
T1:Pol	0 = Off 1 = Negative (active low) 2 = Positive (active high)	Sets the polarity of the output for Channel 1.
T2a	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 2a.
T2a=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 2a.
T2b	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 2b.
T2b=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 2b.
T2:Pol	0 = Off 1 = Negative (active low) 2 = Positive (active high)	Sets the polarity of the output for Channel 2.
T3a	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 3a.
T3a=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 3a.
T3b	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 3b.
T3b=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 3b.

9314E Communication Commands		
Command Name	Parameters	Description
T3:Pol	0 = Off 1 = Negative (active low) 2 = Positive (active high)	Sets the polarity of the output for Channel 3.
T4a	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 4a.
T4a=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 4a.
T4b	-999999998 - +999999998	Sets the delay, in microseconds * 10, for edge 4b.
T4b=	0 - 8 (0=To, 1=1a, 2=1b, etc.)	Sets the sync edge for edge 4b.
T4:Pol	0 = Off 1 = Negative (active low) 2 = Positive (active high)	Sets the polarity of the output for Channel 4.
BEEP	1 - 1000	Beeps the buzzer the specified number of times.
RUN	0 = Disable 1 = Enable	Enable / disables the pulse generator output.
RECALL	0 - 12	Recall a stored configuration.
STORE	1 - 12	Store a configuration.
SHOTS	0 = Reset to zero	Resets shot counter. SHOT ? will return the number of shots.
ECHO	0 = Disable 1 = Enable	Enables/Disables the RS232 echo. The result string is always sent back.
Fmark,	0 = , (comma) 1 = . (period)	Sets the character used as a decimal point on the display.
VOLUME	0 - 9	Sets the key click volume level.

1 SPECIFICATIONS

DELAYS

P CHANNELS Eight (8) independent outputs, with digitally controlled delay and pulsewidth.

P DELAY 0 to 99.9999998 sec

P PULSEWIDTH 400 ns to 99.9999998 sec

P RESOLUTION 200 ns

P ACCURACY 20 ns + .0001 x delay

P TIMEBASE 5 MHz, 25 PPM crystal oscillator

P RMS JITTER 10 ns + .0001 x period, 100 ns max

P TRIG DELAY Ext Trig to To < 10 ms

EXTERNAL TRIG / GATE

P RATE Dc to 1/ (75 μ s + largest delay + period)

P THRESHOLD 3 V_{Dc} (3 mA into optoisolator)

P TRIGGER SLOPE Rising or falling edge

P GATE Active low or active high

P IMPEDANCE 1000 Ω

INTERNAL RATE GENERATOR

P MODES Single shot, burst, duty cycle, continuous, external trigger, external gate

P RATE (To period) 100 μ s to 99.9999998 sec (.01 Hz to 10 KHz)

P ACCURACY 20 ns + .0001 x period

P RMS JITTER 10 ns + .0001 x period

P BURST MODE 1 to 50,000 pulses

OUTPUTS

(T1,T2,T3,T4)

P IMPEDANCE 50 Ω

P SLEW RATE > .2 V/ns

P OVERSHOOT < 100 mV + 10% of pulse amplitude

P AMPLITUDE 1-10V into 50 Ω load 2-20V into high impedance
load manually adjusted, all outputs at same level

P PEAK CURRENT 400 mA per channel

P AVERAGE CURRENT 200 mA average (total for all channels)

COMPUTER INTERFACE

P RS232 9600 Baud. All instrument functions and settings may be controlled over the interface bus.

GENERAL

P STORAGE Twelve (12) complete configurations may be stored and recalled from the front panel or the computer interface.

P DIMENSIONS 7.5" x 9.0" x 4.0"

P WEIGHT 5 lbs.

P POWER < 20 watts @ 120 or 220 Vac

1 MAINTENANCE

Except for fuse replacement, the 9314E should require no maintenance.

Replacing the Fuse

A pair of fuses are mounted in the power entry module. To replace fuses, follow the instructions given below:

1. Unplug the 9314E from power source and remove power cord from the back panel.
2. Remove the fuse holder by pushing down on the center tab and pulling out.
3. Remove the faulty fuses and replace with one of a similar rating, (5 x 20 mm, .125 Amp).
4. Reinstall the fuse holder.
5. Reattach the power cord.

1 CUSTOM FEATURES

None.